

The construction of the chassis of the General Electric Co.'s S.G.3 is perfectly straightforward. A new wiring colour code is employed, of which details are given under "General Notes."

(Continued from previous page.)

General Notes .- A new colour code is used for the wiring in this receiver :-

White, high potential connections to the aerial circuit; green, control grid connections and high potential ends of signal circuits; blue, screen grid connections; orange, connections to the anodes of valves;

black, connections to earth, frame, or low potential ends of signal circuits; slate, connections to H.T.—, where H.T.— is not connected to earth; red, connections to H.T. +; green-white, grid circuit decoupling and the addition of white to the above colours indicates a decoupling connection for the respective circuit.
The filament circuit is wired in black-red

and black-white respectively, the forcer

being the L.T.+ connections.

The condenser C10 across the bias potentio-The condenser CIO across the diss potentio-meter is a 50 mfd. 20 v. working the electrolytic and the positive end is connected to chassis. The anchorage for the negative end is actually on the aerial transformer. Replacing Chassis.—Lay chassis inside cabinet, replace knobs and holding screws.

BUSH RADIO'S S.A.C.5 FIVE-VALVE SUPERHET

Circuit.—The combined first-detector-oscil-Circuit.—The combined first-detector-oscillator, F.C.4 met. (V1) is preceded by a bandpass aerial tuner. Bias is obtained by cathode resistance and A.V.C., and oscillator tuning is in the grid circuit. Coupling to the next valve is by band-pass I.F. transformer (frequency 123 kc.).

The I.F. valve, VP4 met. (V2), has a grid stabilising resistance and is also biased by

stabilising resistance and is also biased by A.V.C. and cathode resistance, the latter being tapped to form a positive bias potentiometer to maintain current flow through the

No signal on M.W.							
Valve	Type.		Electrode	Volts	Ma.		
1	F.C.4 met (7)		anode	226 75	1.8		
2	V.P.4 met (5)		osc. anode anode aux. grid	75 115 75	3.5		
3	354v. met (5)		anode	150	3		
4	Pen. 4V.A. (7)	• •	anode aux. grid	$\frac{235}{250}$	30 5		

VALVE DEADINGS


Westector, which is used as a half-wave

second detector.

Both the D.C. and L.F. outputs from the Westector are utilised, the D.C. being fed A.V.C., and the L.F. through a resistance capacity filter to the grid of the L.F. valve. The diode load is R 11.

The L.F. valve, 354 V or 904 V met. (V3), has a grid stabilising resistance and the grid

has a grid stabilising resistance, and the grid leak is the potentiometer volume control. The (Continued on opposite page.)



Following frequency changing and I.F. stages, the Bush S.A.C.5 has a Westector used for both A.V.C. and signal purposes. an L.F. amplifier resistance coupled to the output pentode.

BUSH MODEL S.A.C.5 SUPERHET (Cont.)



The familiar speaker fret design is used for the S.A.C.5 receiver by Bush Radio, Ltd. The escutcheon incorporates a tuning indicator.

wing coupling is another R.C. filter with

f anode and grid decoupling.

the output valve, a Pen 4VA (V4), is

sed by connecting the grid return lead to a


potentiometer across the speaker field, which
is in the negative H.T. lead. Tone compensation is by a condenser across the primary of the output transformer.

Mains equipment, consists of transformer, full-wave indirectly heated rectifier and two 8 mfd. electrolytic condensers, used for smoothing


Special Notes.—The neon tuning indicator utilises the operating potentials between the negative of the power unit and the V2

•	RESISTANCE	S	
R.	Purpose.	Ohms.	
1	V1 cathode bias		250
2	V1 osc. grid leak		15,000
3	Decoupling V1 grid		.25 meg.
4	Decoupling V1 anode		10,000
2 3 4 5	Decoupling V2 grid		.25 meg.
	V2 grid stabiliser		250
7	V2 cathode bias ptr		250
6 7 8	V2 cathode bias ptr		600
9	Decoupling V2 anode		40,000
10	Voltage dropping to V1 and V	2	,
	aux. grids	٦ I	20,000
11	Westector load		.25 meg.
12	H.F. stopper		50,000
13	H.F. stopper		100,000
14	V3 cathode bias		1,000
15	V3 anode coupling		30,000
16	V3 anode H.T. decoupling		10,000
17	V4 grid leak		.5 meg.
18	V4 grid decoupling		.5 meg.
19	V4 bias ptr		.15 meg.
20	V4 bias ptr		.5 meg.
	Voltage control on neon tube		.25 meg.

CONDENSERS							
No.	Purpose.	Mfd.					
1	Short-circuiting L.W. on aerial						
	coil	.0011					
2	Decoupling V1 grid	.1					
3	V1 cathode by-pass	1.1					
4	V1 osc grid reservoir	.0005					
5	M.W. osc. tracking						
2 3 4 5 6 7 8 9	L.W. osc. tracking						
7	V1 aux. grid by-pass	.1					
8	V1 anode decoupling	.1					
	V2 grid decoupling	1.1					
10	V2 cathode by-pass	.1					
11	V2 anode decoupling	1 .					
12	H.F. by-pass from detector	.0002					
13	L.F. coupling from detector	.005					
14	Tone control circuit, V3 grid	.001					
15	Tone control circuit, V3 grid	.001					
16	V3 cathode by-pass	50 el.					
17	V3 anode decoupling	.5					
18	V3, V4, L.F. coupling	.005					
19	V4 grid decoupling	.5					
20	Tone compensating V4 anode	.005					
21	H.T. smoothing	8					
22	H.T. smoothing	8					
23	Tuning L.S. field	.1					



They are fitted to There are no trimmers on the gang condenser of the S.A.C.5. the coils and are adjusted from below the chassis.



Compact, orderly arrangement of parts is found in the Bush receiver, and the use of assemblies facilitates clean wiring.

anode potential. The actual controlling voltage is that provided by the drop across

The tuning indicator is mounted above the ganged condenser. There are no trimmers on the condenser as these are situated inside the coil cans and can be reached from underneath the chassis as shown in the diagram. Those nearer the front of the chassis are the long-wave trimmers.

The Westector is mounted inside the screening can of the second I.F. transformer.
R3 and C4 are inside the osc. coil can.

Quick Tests .- Between the terminals on the speaker transformer and chassis (note the polarity) :-

- Top. (1) Red, 105 volts negative.
 (2) Blue, H.T. smoothed, 250 volts positive.
 (3) Brown 0.

 - (4) and (6) 0.
 - V4 Green. anode. volts positive.
- (1) Gives the voltage drop across the speaker field resistance 2,000 ohms.

Removing Chassis .- Remove the knobs (grub screws), four screws underneath the cabinet, release the speaker cable from the cleat and lift the chassis out.

General Notes .- The pilot lamps are 3.5 volt type and are wired in series.

Connections to mains transformer (see diagram): R, R, rectifier heater; A, A, rectifier anodes; C, H.T. +; H, H, set heaters; E,

The smoothing condensers, C 21 and C 22, are in one container, the case is negative of C 21, the red lead is the common positive, and the black lead is the negative of C 22.

Soldering tags on the ends of the small resistance condenser panel are used as anchorages for the leads.

The condensers in the blocks are .1 mfd. and the cases are earthed.

The small twisted wire condenser on V1 holder is the second channel suppressor coupling.

Replacing Chassis.—Lay the chassis inside the cabinet, replace holding screws and

knobs, catch the speaker cable under the cleat.

SERVICE EQUIPMENT BY E.M.I.

E.M.I. Service, Ltd., of Sheraton Works, Hayes, has introduced a range of equipment of the service workshop.

The gear includes a bench for two engineers at 12 guineas, an insulation tester at £7 2s. 6d., an oscillator at £8 5s., a cabinet refinishing kit at 17s. 6d., and a stand for the adjustment of gramophone motors and charge units at £1 17s. 6d.

The firm has also prepared detailed instructions for the planning and equipment of both the workshop and office sections of a service department.

A complete administration system has been worked out and the necessary stationery and files are available.